


LuminetSM and Standard Television Equipment

CLIKR-5 Remote—LuminetSM and Standard Video Service UR5U-8700L and UR5U-8720L





There are two ways you can Program your Remote:

- Program your remote using the Pre-Programmed 3-Digit Code Method.
- Program your remote using the Auto-Search Method.

The Pre-Programmed Code Method allows you to setup all the buttons at once by entering 3-digit code numbers that correspond to a particular component's manufacturer/brand, so it's the fastest and easiest of the two methods. (Code tables follow these instructions.)

The Auto-Search Method scans through all the codes in the remote control, one at a time.

- This pertains to all programming steps. When you are in setup mode, a component LED will light for 30 seconds. If you do not press a button within 30 seconds, the LED light will turn off and exit setup mode and you will need to start over.







Pre-Programmed 3-Digit code Method Instructions:

1. Turn on the component you want to program (TV, VCR, DVD or AUX).
2. Press the **COMPONENT (TV, VCR, DVD or AUX)** button to be programmed and press the **OK/SEL** button simultaneously for 3 seconds. The component LED light will turn on for 30 seconds indicating the unit is ready to be programmed.
3. Point the remote control toward the component and enter the 3-digit code number assigned to your brand.

Record your Component Setup Codes:

TV Setup code Number	<input type="text"/>	<input type="text"/>	<input type="text"/>
VCR Setup code Number	<input type="text"/>	<input type="text"/>	<input type="text"/>
DVD Setup code Number	<input type="text"/>	<input type="text"/>	<input type="text"/>
AUX Setup code Number	<input type="text"/>	<input type="text"/>	<input type="text"/>

- If the 3-digit code number you just entered is correct, the component will turn off. If it did not turn off, continue entering code numbers listed for that brand until the component turns off.

4. After you've entered the correct code number and the component has turned off, press the **POWER**  button to turn the component back on. Now it is time to test the **VOL**   and **MUTE**  buttons for the TV or **PLAY**  and **STOP**  buttons for VCR and DVD to make sure they all work. If any of the functions do not work as they should, repeat from step 3 using the next 3-digit code number listed for that brand until you find the best component code.
5. Once you have found the correct 3-digit code, save it by pressing the same **COMPONENT (TV, VCR, DVD or AUX)** button one more time. The component LED light will blink twice to confirm that the code was successfully stored. Now, program the rest of your components by repeating steps 1-5.

- If the Pre-Programmed Method did not work, or if the Code Tables do not list your component brand, use the Auto-Search Method following these instructions.

Auto-Search Method Programming Instructions:

1. Turn on the component you want to program (TV, VCR, DVD or AUX).
2. Press the **COMPONENT** (TV, VCR, DVD or AUX) button to be programmed and press the **OK/SEL** button simultaneously for 3 seconds. The component LED light will turn on for 30 seconds indicating the unit is ready to be programmed.
3. Point the remote toward the component and press the **CH ▲▼** buttons one step at a time or keep it pressed. The remote will emit a series of **ON/OFF** commands. Release the **CH ▲▼** buttons as soon as the component turns off.
4. Test functions. (Same as for 3-digit code Programming Method). If any of the functions do not work as they should, repeat from Step 3 using **CH ▲▼** buttons to find the correct code.
5. Save the code. (Same as for 3-digit code Programming Method). Now, repeat the Auto-Search Method for those components you could not program earlier with the Pre-Programmed Method.

Visit www.universalremote.com for additional information about your remote control.

CLIKR-5 CODES

STB-IPTV

ADB 254 255 315 259
 AMINO 249 256 257 260 261
 ATANDT 251
 CISCO 313 251 316
 COMCAST 313
 ENTONE 155 258
 MYRIO 254 255
 MOTOROLA 253
 NOW TV 314
 PACE 313
 SCIENTIFIC ATLANTA 251
 WEGENER 250

STB-CABLE CONVERTERS

SCIENTIFIC ATLANTA 001 003 041
 042 045 046
 PIONEER 001 103 034 051 063 076
 105
 PACE 001 005 002
 SAMSUNG 001 030
 MOTOROLA 002 111 148
 DIGEO 153
 GENERAL INSTRUMENT 005 103
 104
 HAMLIN 049 050 055
 HITACHI 103 055
 JERROLD 005 004 103 005 003 008
 009 010 069
 MAGNAVOX 010 012
 MEMOREX 052
 MOXI 111 252 153
 NFUSION 192
 PANASONIC 044 047
 PHILIPS 006 012 013 020 085
 PULSAR 052
 RCA 047
 REGAL 049 050
 REGENCY 057
 SKY 230 204
 SONY 108
 SPRUCER 047
 TELNET 354

TOCOM 039 040 056
 TOSHIBA 052
 VIEWSTAR 012 015
 ZENITH 052 060 093 100

TV

A MARK 112 143
 ABEX 025
 ACCURIAN 036
 ADMIRAL 072 251 333
 ADVENT 247 388
 ADVENTURA 002
 AIKO 103
 AKAI 116 146 248 404 405 473 475
 323 387 391
 ALBATRON 017
 ALERON 028
 AMERICA ACTION 043
 AMPRO 073
 AMSTRAD 052
 ANAM 043 054 056 080 112
 AOC 116 363 112 058
 APEX 572
 APEX DIGITAL 006
 AQUAVISION 573 574
 ASTAR 477
 AUDIOVOX 076 454 388
 AVENTURA 052
 AVION 441
 AXION 039
 BELCOR 116
 BELLANDHOWELL 333 072
 BENQ 423 600
 BOXLIGHT 266
 BRADFORD 043
 BROCKWOOD 116
 BROKSONIC 238
 BYDESIGN 031 032
 CANDLE 116 002 003 363
 CAPEHART 058
 CARY AUDIO DESIGN 266
 CELEBRITY 001
 CENTURION 116
 CETRONIC 043
 CHANGHONG 247

CITIZEN 116 002 003 363 043 258
 103 143
 CLARION 043
 CLASSIC 043
 CLP CLASSIC 333
 COLORTYME 116
 CONCERTO 363
 CONCIERGE 073
 CONTEC 043 050 051
 CORNEA 116
 CORONADO 143
 CRAIG 043 054
 CROSLEY 164
 CROWN 043 143
 CURTIS MATHES 116 258 363 143
 CXC 043
 CYBERHOME 015
 DAEWOO 363 016 043 044 076 103
 114 125 127 143
 DAYTRON 363 143
 DELL 320 164 363
 DIGITAL PROJECTION 570
 DIMENSIA 333
 DREAMVISION 235
 DUKANE 011 025
 DUMONT 116 073
 DURABRAND 096 052
 DWIN 257
 DYNASTY 043
 DYNEX 400
 EIKI 187
 ELECTROBAND 001
 ELECTROGRAPH 466
 ELECTROHOME 143 024 076 196
 ELEKTRA 072
 ELEMENT 363 494 526
 EMERSON 028 048 043 155 005 116
 363 047 050 051 076 096 143 153
 154 052 514
 ENVISION 116
 EPSON 324 590
 ESA 323
 FISHER 007 057
 FUJITSU 246 198 410
 FUNAI 028 043 052

FUTURETECH 043
 GATEWAY 242 268
 GE 073 116 008 009 034 056 074 155
 333 363
 GEM 391
 GIBRALTER 116 073
 GO VIDEO 026
 GOLDSTAR 113 116 102 363 106 112
 127 143
 GRUNPY 028 043
 HAIER 363 501
 HALL MARK 363
 HANNSPREE 349 381
 HARLEY DAVIDSON 028
 HARVARD 043
 HAVERMY 081
 HELLO KITTY 076
 HIMITSU 043
 HISENSE 419 442
 HITACHI 011 166 009 010 012 023
 075 143 158 072 363 250 587
 HP 378 316 327 421
 HUMAX 518
 HYUNDAI 337 338
 ILO 472 399
 INFINITY 164
 INFOCUS 333 230 547 548 470 532
 564 595
 INITIAL 035 282
 INSIGNIA 350 400 052 164 403 454
 457
 INTEQ 073
 JANEIL 002
 JBL 164
 JCB 001
 JCPENNEY 024 116 008 009 030 065
 258 143 333 363
 JENSEN 013
 JVC 038 034 001 083 199 210 533
 581
 KAWASHO 116 001
 KEC 043
 KENWOOD 116 001
 KLEGG 466
 KLOSS 002 059



KMC 143
KNOLL SYSTEMS 230
KONKA 457
KREISEN 530
KTV 043 116 143 154
KURAZAI 072
LG 363 113 116 102 106 112 127 143
569 284
LITEON 268
LODGENET 072
LOEWE 164
LOGIK 072
LUXMAN 363
LXI 166 007 138 052 251 333 164
MAGNAVOX 164 059 116 003 060
061 363 127 022 333 094 226 390
467 431
MAJESTIC 333 072
MARANTZ 116 164 281 562 584
MATSUI 164
MATSUSHITA 080
MAXENT 242
MEGATRON 116 011
MEMOREX 007 072 363
MGA 116 363 024 028 042
MIDLAND 333 073
MINTEK 362
MINUTZ 008
MISAKAI 052
MITSUBISHI 124 109 024 028 040
042 146 363 348 450
MONIVISION 017
MONTGOMERY WARD 333 072
MOTOROLA 081
MTC 116 363 258
MULTITECH 043
NAD 138 025
NEC 272 197134 116 040 016 024
056 019 262 236 281 575
NET TV 242
NIKEI 043
NIKKO 116
NIKO 527
NORCENT 390
NORWOOD MICRO 027
NTC 103
NUVISION 351 567
OLEVIA 432 363 333
ONKING 043
ONWA 043
OPTIMUS 025
OPTOMA 265 249
OPTONICA 019 251
ORION 096
PANASONIC 080 034 056 164 208
359 552 524
PHILCO 116 003 059 060 164 363
024 056
PHILIPS 164 005 093 038 116 003
363 059 127 206 431 333 161 594
PILOT 116

PIONEER 234 135 025 018 023 116
393 272 520 582
POLAROID 388 323 328 353 354 355
356 494 387 391 505 506 508
PORTLAND 363 143
PRINCETON 004
PRISM 034
PROSCAN 333
PROTON 363 112 058 143 171 172
033 528
PROTRON 392 398 498 499 500
PROVIEW 494
PROX 572
PULSAR 116 073
QUASAR 034 056
RADIO SHACK 019 363 143 043 127
RCA 333 065 116 363 024 056 152
023 074 161 588
REALISTIC 007 019 043 047
REVOLUTION HD 466
RUNCO 182 073 395 416 072 342
SAMPO 116 058 363 242
SAMSUNG 258 050 089 105 363 127
143 333 228 229
SAMSUX 116
SANSEI 076
SANSUI 096 400
SANYO 166 007 020 053 057 082 187
511 266
SCEPTRE 276
SCOTCH 116
SCOTT 028 043 048 143 363 497
SEARS 030 363 007 028 057 143 094
333 082 166 138
SELECO 205 011
SHARP 251 019 014 028 029 363 022
143 175 308
SHENG CHIA 081
SHERWOOD 349
SHOGUN 116
SIGNATURE 072
SIMPSON 003
SONY 001
SOUNDESIGN 028 363 003 043
SOVA 041
SOYO 528 033
SPECTRICON 112
SPECTRONIQ 499 500
SQUAREVIEW 052
SSS 363 043
STARLITE 043
SUPERSCAN 052 081
SUPRA 116
SUPRE MACY 002
SUPREME 001
SVA 328
SYLVANIA 116 003 052 059 060 164
044 333 127 514 593
SYMPHONIC 052
SYNTAX OLEVIA 432 363 333
TANDY 251

TATUNG 056
TECHNICS 034 080
TECHNOL ACE 028
TECHVIEW 045 557
TECHWOOD 363
TEKNIKA 002 003 363 024 028 043
072 258 143
TELEFUNKEN 037 046
TELERENT 072
TERA 172
THOMSON 049 055
TMK 363
TNCI 073
TOSHIBA 138 030 007 040 258 325
230
TOTEVISION 143
TRUTECH 529
TVS 096
UNIVERSAL 008 009
VICTOR 038
VIDEO CONCEPTS 146
VIDIKRON 174 164 188 192 342
VIDTECH 363
VIEWSONIC 242 389
VIKING 002
VIORE 472 592
VISCO 526
VITO 363
VIZIO 386 387
WARDS 363 008 009 019 028 060
061 072 074 143 164 034
WAYCON 015
WESTINGHOUSE 076 276 435 001
WINBOOK 339
YAMAHA 116 363 370
YORK 363
YUPITERU 043
ZENITH 363 073 072 095 103
ZONDA 112

TV-LCD AND PLASMA TVS

ACCURIAN 036
ADVENT 247 388
AKAI 404 405 473 475 323 387 391
AOC 116 363
APEX 572
APEX DIGITAL 006
AQUAVISION 573 574
ASTAR 477
AUDIOVOX 454 388 076
AVION 441
AXION 039
BENQ 600
CHANGHONG 247
CYBERHOME 015
DAEWOO 076 363
DELL 320 164 363
DURABRAND 052
DWIN 257
DYNEX 400
ELECTROGRAPH 466

ELEMENT 363 494 526
EMERSON 514 363 076 052
ESA 323
FUJITSU 246 198
FUNAI 052
GATEWAY 242 268
GO VIDEO 026
HAIER 363 501
HANNSPREE 349 381
HISENSE 419 442
HITACHI 011 363
HP 378 316 327 421
HUMAX 518
HYUNDAI 337 338
ILO 472
INFOCUS 547 470
INITIAL 035 282
INSIGNIA 350 400 052 164 403 454
457
JVC 038 210 581
KLEGG 466
KONKA 457
KREISEN 530
LG 363 569 113 116 284
LITEON 268
LOEWE 164
MAGNAVOX 164 363 226 390 467
431
MARANTZ 116 164 281
MAXENT 242
MINTEK 362
MITSUBISHI 124 363
NEC 272 262 575
NIKO 527
NORCENT 390
NORWOOD MICRO 027
NUVISION 351 567
OLEVIA 432 363 333
PANASONIC 080 164 208 552 524
PHILIPS 164 363 431 161 594
PIONEER 234 135 393 272 520 582
POLAROID 388 323 328 353 356 494
387 391 505 506
PRINCETON 004
PROTON 033 528
PROTRON 392 398 498 499 500
PROVIEW 494
PROX 572
RCA 333 363 161 588
REVOLUTION HD 466
RUNCO 395 416
SAMPO 363 242
SAMSUNG 258 228 229
SANSUI 096 400
SANYO 166 007
SCEPTRE 276
SHARP 251 363
SHERWOOD 349
SONY 001
SOVA 041
SOYO 528 033

SPECTRONIQ 499 500
 SVA 328
 SYLVANIA 052 164 333 514
 SYMPHONIC 052
 SYNTAX OLEVIA 432 363 333
 TATUNG 056
 TECHVIEW 045 557
 TOSHIBA 138 258 325
 TRUTECH 529
 VIEWSONIC 242 389
 VIORE 472 592
 VISCO 526
 VITO 363
 VIZIO 386 387
 WESTINGHOUSE 076 276 435 001
 WINBOOK 339
 YAMAHA 116 363
 ZENITH 363 073 072

TV-PROJECTION TVS

AKAI 404 405 473 475
 DAEWOO 076
 EPSON 324
 HITACHI 011
 HP 378
 INFOCUS 333 548
 JVC 038
 LG 363
 LOEWE 164
 MAGNAVOX 164 333
 MITSUBISHI 109
 OPTOMA 265
 PANASONIC 080 524
 PHILIPS 164 431
 RCA 333
 SAMSUNG 258
 SANYO 166 007 187
 SHARP 251
 SONY 001
 TOSHIBA 138
 ZENITH 363 073 072

TV-PROJECTORS

BENQ 423
 BOXLIGHT 266
 DIGITAL PROJECTION 570
 DREAMVISION 235
 EPSON 590
 FUJITSU 410
 HITACHI 250
 INFOCUS 230 532 564 595
 JVC 199 533
 KNOLL SYSTEMS 230
 MARANTZ 281 562 584
 MITSUBISHI 348
 NEC 236 281
 OPTOMA 249
 PANASONIC 359
 RUNCO 342 182
 SANYO 511 266
 SELECO 205

SHARP 308
 SIM2 205
 TOSHIBA 230
 VIDIKRON 342 174 188 192
 YAMAHA 370

VCR

ADMIRAL 025 053
 ADVENTURA 034
 AIKO 117
 AIWA 034 161
 AKAI 016 146 043 124 125
 AMERICA ACTION 117
 AMERICAN HIGH 145
 AMPRO 072
 ANAM 145
 ASHA 102
 AUDIO DYNAMICS 012 039 043
 AUDIOVOX 101
 BEAUMARK 102
 BROKSONIC 035 037 129
 CALIX 101
 CAPEHART 108
 CCE 024 117
 CITIZEN 101 117
 COLT 024
 CRAIG 003 022 102
 CURTIS MATHES 145
 CYBERNEX 102
 DAEWOO 111 116 117 005 010 108
 110 120
 DAYTRON 108
 DBX 012 039 043
 DYNATECH 034 053
 ELECTROHOME 059
 ELECTROPHONIC 101
 EMERSON 006 029 035 017 025
 034 036 037 101 129 131 153 162
 116 145
 FISHER 003 010 008 009
 FUJI 145
 FUNAI 034
 GARRARD 034
 GE 072 144 147 145
 GO VIDEO 132 136 155 115 102
 GOLDSTAR 101 114 013 012 123
 GRADIENTE 034
 HARLEY DAVIDSON 034
 HARMAN KARDON 012
 HARWOOD 024
 HITACHI 026 150 034 043 160 013
 HQ 034
 INSTANTREPLAY 145
 JCL 145
 JCPENNEY 012 013 015 101 102
 JENSEN 043
 JVC 048 043 130 150 012 145
 KEC 101
 KENWOOD 048 034
 KLH 024
 KODAK 101 145

LG 101 114 013 012 123
 LLOYD 034
 LOGIK 024
 LXI 034 003 009 017
 MAGIN 102
 MAGNAVOX 067 034 164 145
 MARANTZ 067 012 145
 MARTA 101
 MATSUSHITA 145
 MEI 145
 MEMOREX 101 003 010 034 053 072
 102 139 145
 MGA 059
 MGN TECHNOLOGY 102
 MINOLTA 013
 MITSUBISHI 059 061 151 013 051
 MOTOROLA 053 145
 MTC 034 102
 MULTITECH 024 034
 NEC 012 039 043 048
 NIKKO 101
 NOBLEX 102
 NORDMENDE 043
 OLYMPUS 145
 OPTIMUS 101
 OPTONICA 053
 ORION 025
 PANASONIC 070 145 163 167
 PENTAX 013 145
 PHILCO 034 067 145
 PHILIPS 067 034 101 071 145
 PILOT 101
 PIONEER 021 013 048
 PORTLAND 108
 PROFITRONIC 102
 PROTEC 024
 PULSAR 072
 QUARTZ 002
 QUASAR 145
 RADIO SHACK 123
 RADIX 101
 RANDEX 101
 RCA 144 147 145 013 034 102
 REALISTIC 003 008 010 034 053 101
 145 102
 RICO 058
 RUNCO 148
 SAMSUNG 102 113 115 120 144
 147 125
 SANKY 053
 SANSUI 022 043 048
 SANYO 003 010 102
 SCOTT 017 037 120 129 131
 SEARS 003 008 010 013 101 009 017
 073 112
 SHARP 053 165 145
 SHINTOM 024
 SHOGUN 102
 SIGNATURE 034
 SINGER 024
 SONY 001 057 058 003 053 154 145

SOUNDESIGN 034
 STS 013
 SYLVANIA 034 059 067 145
 SYMPHONIC 034
 TANDY 010 034
 TATUNG 039 043
 TEAC 034 039 043
 TECHNICS 070 145
 TEKNIKA 019 034 101 145
 THOMAS 034
 TMK 006
 TOSHIBA 131 008 059 013 120
 TOTEVISION 101 102
 UNITECH 102
 VECTOR RESEARCH 012
 VICTOR 048
 VIDEO CONCEPTS 012 034
 VIDEOSONIC 102
 VILLAIN 034
 WARDS 003 013 017 024 034 053
 131 145 102
 WESTINGHOUSE 024 025
 XR-1000 024 034 145
 YAMAHA 012 034 039 043
 ZENITH 072 080 056 048 101 034
 058

VCR-TV/VCR COMBOS

AMERICA ACTION 117
 DAEWOO 005 117
 EMERSON 153
 FUNAI 034
 GOLDSTAR 101 123
 HARLEY DAVIDSON 034
 HITACHI 034
 JCPENNEY 101
 LG 101 123
 LLOYD 034
 MAGNAVOX 034 067
 MEMOREX 101
 PANASONIC 070 167
 PHILIPS 034 067
 RADIO SHACK 123
 RCA 034 144
 SEARS 101
 SONY 057 154
 SYLVANIA 067
 SYMPHONIC 034
 THOMAS 034
 ZENITH 034

DVD

ACCURIAN 003 268
 ADCOM 157
 ADVENT 005
 AIWA 146
 AKAI 281
 ALLEGRO 091
 ALPINE 098
 AMW 006 007
 APEX DIGITAL 087 111 115



- ARCAM 122
ASPIRE DIGITAL 008 009
AUDIOVOX 003 010 014 015 149
BEL CANTO DESIGN 016
BLAUPUNKT 111
BROKSONIC 130
BUFFALO 264
CALIFORNIA AUDIO LABS 021 124
CAMBRIDGE AUDIO 323 333
CARY AUDIO DESIGN 174 266
CENTRIOS 019
CINEVISION 091
CITIZEN 020
COBY 260
CYBERHOME 271
DAEWOO 132
DENON 080 173 138 329
DIAMOND VISION 037 038 039
DISNEY 040 096
DURABRAND 091
DVD 2000 017
EMERSON 091 143
ENTERPRISE 074
ESA 022 143
FISHER 147
FUNAI 143
GATEWAY 222
GE 027
GO VIDEO 137 091 220 221 222
GOLDSTAR 091
GPX 044 045
GRADIENTE 021
GREENHILL 111
GRUNDIG 083
HARMAN KARDON 084 140
HITACHI 101
HITEKER 087
ILO 268
INITIAL 111
INSIGNIA 143 292 297 091 096
INTEGRA 142 180 280 273 338
JATON 046
JBL 084
JSI 047
JVC 012
JWIN 048 050
KAWASAKI 149
KENWOOD 151
KISS 279
KLH 135
KONKA 051 052 054 055
KOSS 047 058 059
KREISEN 060
KRELL 104
LASONIC 061 062
LEXICON 148
LG 091 057 074
LITEON 264 265 268
LOEWE 063
MAGNAVOX 066 096 282
MALATA 267
MARANTZ 066 332
MCINTOSH 125
MEMOREX 040 096 163
MERIDIAN 153
MICROSOFT 027 206
MINTEK 111 282
MITSUBISHI 017
MYRYAD 102 134
NAD 088
NAKAMICHI 103
NESA 111
NEUNEO 067
NEXXTECH 068
NORCENT 005 006 007 069 071 072 073
ONKYO 076 141 180 273 338
OPPO 266 341
OPTIMUS 023
ORION 130
ORITRON 058
PANASONIC 144 150 285 138 021 346 347
PARASOUND 245
PHILIPS 066 276 317 344
PHILIPS MAGNAVOX 141 066
PIONEER 023 099 131 304 337
POLAROID 233 284 295 297
POLK AUDIO 141 066
PRESIDIAN 003 096
PRIMA 005
PRIMARE 193 194
PRINCETON 078
PROSCAN 027
RCA 027 307
RIO 091
RJTECH 269
ROTEL 204
SAMPO 081 082 085
SAMSUNG 070 165 137 159 275
SANSUI 154
SANYO 147
SEARS 130
SENSORY SCIENCE 222
SHARP 094
SHERWOOD 245 345
SHINSONIC 033
SONIC BLUE 091
SONY 001 033 145 191 286 241 242 243 340 343
SPECTRONIQ 310
SUNGALE 090 223
SUPERSCAN 143
SVA 092 093
SYLVANIA 143
SYMPHONIC 143
TAG MCLAREN 156
TATUNG 102
TEAC 023 270
TECHNICS 138
TECHWOOD 088
THETA DIGITAL 023
THOMPSON 027
TOSHIBA 130 141 164 188 273
TRUTECH 293
URBAN CONCEPTS 035
US LOGIC 111 282
VENTURER 149
VINC 161 308
X-BOX 027 206
YAMAHA 089 066 197 138 334
ZENITH 057 074 091
- DVD-TV/DVD/VCR COMBOS**
DURABRAND 143
EMERSON 143
ESA 143
INSIGNIA 143
MAGNAVOX 143
PANASONIC 144
SUPERSCAN 143
SV2000 143
SYLVANIA 143
SYMPHONIC 143
TOSHIBA 164
- DVD-DVD/VCR COMBOS**
GO VIDEO 137
PANASONIC 150
PHILIPS 066
RCA 027
SAMSUNG 137 159
SANSUI 154
SONY 145
TOSHIBA 141
ZENITH 091
- AUX-AUDIO**
ADCOM 082 092 225 161 269 356
AIWA 170 018 104 202 203 213 211 188 699
AKAI 189
ANTHEM 335 337
ARAGON 687
ARCAM 141 077
ATLANTIC TECHNOLOGY 342
AUDIO FILE 071
B AND K 096 097
BOSE 070 170 224 347 409 460 532
BOSTON ACOUSTICS 447
CAMBRIDGE AUDIO 684
CARVER 006 028 061 071 201 214 226 185 013 077 284
CARY AUDIO DESIGN 378
CITATION 148
CLARION 026
DELPHI 515 556
DENON 109 215 230 234 330 340 679 564 569
DIGITAL PROJECTION 660
DVICO 570
ELAN 057 290
ENLIGHTENED AUDIO 099 098
ESCIENT 451
FISHER 214 182
FLEXTRONICS 378
FOSGATE AUDIONICS 148 342
GOLDSTAR 008
HARMAN KARDON 148 233 077 028 118 318
HITACHI 020
INSIGNIA 589
INTEGRA 275 017 046 108 080 209
- DVD-BLU-RAY AND HD DVD**
DENON 329
INSIGNIA 096
INTEGRA 273 338
LG 091
MAGNAVOX 096
MARANTZ 332
ONKYO 273 338
OPPO 341
PANASONIC 285 346
PHILIPS 344
PIONEER 304
SAMSUNG 275
SHERWOOD 345
SONY 286 340
TOSHIBA 273
YAMAHA 334
- DVD-DVD RECORDERS**
GO VIDEO 220 221 222
CYBERHOME 271
ILO 268
KISS 279
LITEON 265 268
MAGNAVOX 096
PANASONIC 138
PHILIPS 317
RCA 027
SAMSUNG 301
SENSORY SCIENCE 222
SONY 191
TOSHIBA 188 273
- DVD-TV/DVD COMBOS**
AIWA 146
AKAI 281
AUDIOVOX 284
DURABRAND 143
ESA 143
FUNAI 143
INSIGNIA 292 297 143
MAGNAVOX 282
MINTEK 282
POLAROID 284 295 297
SAMSUNG 165
SV2000 143
SYLVANIA 143
SYMPHONIC 143
TOSHIBA 130
TRUTECH 293

381
 JAMO 398 399
 JCPENNEY 216
 JVC 163 191 114 279 291
 KEF 530
 KENWOOD 026 066 145 192 182 005
 280 374
 KLEGG 686
 KLH 331
 KLIPSCH 687
 KOSS 216 573
 KRELL 072 384 672
 LEXICON 120 235 236 237 357 360
 LINN 124 377
 LUXMAN 009 139 052 165 115 004
 MAGNAVOX 086 164 152 077
 MARANTZ 006 028 031 040 063 185
 186 265 289 492
 MCINTOSH 238 286 311
 MERIDIAN 100 012 013 628
 MITSUBISHI 242 204
 MONDIAL 157 158 042 043 081 112
 MYRYAD 077
 NAD 186 113 598
 NAKAMICHI 040 244 245 172 183
 287
 NEC 176
 NILES 403
 NIRO 343
 ONKYO 275 017 046 108 080 209
 552 381
 OPTIMUS 026 041
 OUTLAW 342
 PANASONIC 032 195 219 177 292
 626 516
 PARASOUND 129 130 132 261 294
 295 333 334
 PHILIPS 249 250 063 690
 PIONEER 014 039 044 069 168 116
 035 063 198 480 556 513
 POLKAUDIO 556 685
 PROCEED 144 268
 RCA 010 048 117 156 067 288
 REALISTIC 019 073 075 095
 ROTEL 074 083 085 654
 RUSSOUND 445
 SAMSUNG 016 653 571
 SANSUI 040 048 110 063 065 228
 SANYO 214
 SCOTT 019
 SHARP 026 094 175 652
 SHERWOOD 024 102 106 447 370
 SIRIUS 555 585 767 588
 SONY 001 018 247 248 166 101 184
 218 271 380 560 612
 SOUNDESIGN 036
 SUNFIRE 344 345 182
 TEAC 005 019 049 040 212 217
 TECHNICS 122 176 193 219 178 177
 200 257 262
 THETA DIGITAL 136

TOSHIBA 060 087 198 278 510
 XM SATELLITE RADIO 515 556
 YAMAHA 026 253 169 067 173 205
 264 232 089 264 274 715 717
 ZENITH 143 210

AUX-DVR (TIVO)

DIRECTV 819
 HUGHES 817
 HUMAX 817
 ICREALTIME 784
 MOXI 782
 PHILIPS 790 817
 RCA 809
 REPLAY NETWORKS 775
 SONY 804 805
 TIVO 790 817
 TOSHIBA 817

AUX-HOME THEATER SYSTEMS

AIWA 699
 BOSE 347 409 460
 DENON 564
 INSIGNIA 589
 JAMO 398
 KEF 530
 KOSS 573
 NAD 598
 NIRO 343
 ONKYO 552
 PANASONIC 516
 PHILIPS 690 705
 PIONEER 513
 POLKAUDIO 685
 ROTEL 654
 SAMSUNG 571 653
 SHARP 652
 SONY 317 319 321 322 324
 TOSHIBA 510

AUX-TUNERS AND SATELLITE RADIOS

ANTEX ELECTRONICS 588
 BOSE 532 170
 DELPHI 515
 NEXUS AUDIO 751
 PIONEER 556
 RUSSOUND 445
 SIRIUS 555 585 767
 SONY 380
 XM SATELLITE RADIO 515 556
 ZEEVEE 611

AUX-IPOD CONTROLS

APPLE / IPOD 824 828
 BOSE 827
 DENON 830 559
 DLO 418
 GRIFFIN 835
 KENSINGTON 825
 MARANTZ 834

ONKYO 833
 SONANCE 831

AUX-MEDIA PCS

ACER 820
 APPLE TV 836
 DELL 820
 DENON 830
 DLINK 832 838
 GATEWAY 820
 HAUPPAUGE 821 822
 HP 820
 KEYSpan 823
 LINKSYS 566
 NETGEAR 837
 ROKU 565
 SONY 820
 TOSHIBA 820
 WINBOOK 820

AUX-GAMING SYSTEMS

AUDIO AUTHORITY 622
 LOGITECH 658
 MICROSOFT / XBOX 851
 MICROSOFT / XBOX 360 826
 SONY / PS2 / PS3 829 498

AUX-LIGHTING CONTROLS

COLORADIO VNET 849
 LEVITON 850
 LIGHTOLIER CONTROLS 848
 LITE TOUCH 843 844
 LUTRON 839 841 341
 RAKO 846 847
 X-10 840 842 845

AUX-DIGITAL TO ANALOG CONVERTER BOX

DIGITAL STREAM 609
 SCHMARTZ 648
 SKARDIN 610
 SONY 646 647
 ZENTECH 610
 ZENITH 567

DVD

ACCURIAN 003 268
 ADCOM 157
 ADVENT 005
 AIWA 146
 AKAI 281
 ALLEGRO 091
 ALPINE 098
 AMW 006 007
 APEX DIGITAL 087 111 115
 ARCAM 122
 ASPIRE DIGITAL 008 009
 AUDIOVOX 003 010 014 015 149
 BEL CANTO DESIGN 016
 BLAUPUNKT 111
 BROKSONIC 130
 BUFFALO 264
 CALIFORNIA AUDIO LABS 021 124
 CAMBRIDGE AUDIO 323 333
 CARY AUDIO DESIGN 174 266
 CENTRIOS 019
 CINEVISION 091
 CITIZEN 020
 COBY 260
 CYBERHOME 271
 DAEWOO 132
 DENON 080 173 138 329
 DIAMOND VISION 037 038 039
 DISNEY 040 096
 DURABRAND 091
 DVD 2000 017
 EMERSON 091 143
 ENTERPRISE 074
 ESA 022 143
 FISHER 147
 FUNAI 143
 GATEWAY 222
 GE 027
 GO VIDEO 137 091 220 221 222
 GOLDSTAR 091
 GPX 044 045
 GRADIENTE 021
 GREENHILL 111
 GRUNDIG 083
 HARMAN KARDON 084 140
 HITACHI 101
 HITEKER 087
 ILO 268
 INITIAL 111
 INSIGNIA 143 292 297 091 096 349
 INTEGRA 142 180 280 273 338
 JATON 046
 JBL 084
 JSI 047
 JVC 012
 JWIN 048 050
 KAWASAKI 149
 KENWOOD 151
 KISS 279
 KLH 135

KONKA 051 052 054 055
 KOSS 047 058 059
 KREISEN 060
 KRELL 104
 LASONIC 061 062
 LEXICON 148
 LG 091 057 074 350
 LITEON 264 265 268
 LOEWE 063
 MAGNAVOX 066 096 282
 MALATA 267
 MARANTZ 066 332
 MCINTOSH 125
 MEMOREX 040 096 163
 MERIDIAN 153
 MICROSOFT 027 206
 MINTEK 111 282
 MITSUBISHI 017
 MYRYAD 102 134
 NAD 088
 NAKAMICHI 103
 NESA 111
 NEUNEO 067
 NEXXTECH 068
 NORCENT 005 006 007 069 071 072 073
 ONKYO 076 141 180 273 338
 OPPO 266 341
 OPTIMUS 023
 ORION 130
 ORITRON 058
 PANASONIC 144 150 285 138 021 346 347
 PARASOUND 245
 PHILIPS 066 276 317 344
 PHILIPS MAGNAVOX 141 066
 PIONEER 023 099 131 304 337
 POLAROID 233 284 295 297
 POLK AUDIO 141 066
 PRESIDIAN 003 096
 PRIMA 005
 PRIMARE 193 194
 PRINCETON 078
 PROSCAN 027
 RCA 027 307
 RIO 091
 RJTECH 269
 ROTEL 204
 SAMPO 081 082 085
 SAMSUNG 070 165 137 159 275
 SANSUI 154
 SANYO 147
 SEARS 130
 SENSORY SCIENCE 222
 SHARP 094
 SHERWOOD 245 345
 SHINSONIC 033
 SONIC BLUE 091
 SONY 001 033 145 191 286 241 242 243 340 343 351
 SPECTRONIQ 310

SUNGALE 090 223
 SUPERSCAN 143
 SVA 092 093
 SYLVANIA 143
 SYMPHONIC 143
 TAG MCLAREN 156
 TATUNG 102
 TEAC 023 270
 TECHNICS 138
 TECHWOOD 088
 THETA DIGITAL 023
 THOMPSON 027
 TOSHIBA 130 141 164 188 273
 TRUTECH 293
 URBAN CONCEPTS 035
 US LOGIC 111 282
 VENTURER 149
 VINC 161 308
 X-BOX 027 206
 YAMAHA 089 066 197 138 334
 ZENITH 057 074 091

DVD-BLU-RAY AND HD DVD

DENON 329
 INSIGNIA 096 349
 INTEGRA 273 338
 LG 091 350
 MAGNAVOX 096
 MARANTZ 332
 ONKYO 273 338
 OPPO 341
 PANASONIC 285 346
 PHILIPS 344
 PIONEER 304
 SAMSUNG 275
 SHERWOOD 345
 SONY 286 340 351
 TOSHIBA 273
 YAMAHA 334

DVD-DVD RECORDERS

GO VIDEO 220 221 222
 CYBERHOME 271
 ILO 268
 KISS 279
 LITEON 265 268
 MAGNAVOX 096
 PANASONIC 138
 PHILIPS 317
 RCA 027
 SAMSUNG 301
 SENSORY SCIENCE 222
 SONY 191
 TOSHIBA 188 273

DVD-TV/DVD COMBOS

AIWA 146
 AKAI 281
 AUDIOVOX 284
 DURABRAND 143
 ESA 143

FUNAI 143
 INSIGNIA 292 297 143
 MAGNAVOX 282
 MINTEK 282
 POLAROID 284 295 297
 SAMSUNG 165
 SV2000 143
 SYLVANIA 143
 SYMPHONIC 143
 TOSHIBA 130
 TRUTECH 293
 DVD-TV/DVD/VCR COMBOS
 DURABRAND 143
 EMERSON 143
 ESA 143
 INSIGNIA 143
 MAGNAVOX 143
 PANASONIC 144
 SUPERSCAN 143
 SV2000 143
 SYLVANIA 143
 SYMPHONIC 143
 TOSHIBA 164

DVD-DVD/VCR COMBOS

GO VIDEO 137
 PANASONIC 150
 PHILIPS 066
 RCA 027
 SAMSUNG 137 159
 SANSUI 154
 SONY 145
 TOSHIBA 141
 ZENITH 091

AUX-AUDIO

ADCOM 082 092 225 161 269 356
 AIWA 018 104 202 203 213
 AKAI 189
 ANTHEM 335 337
 ARAGON 687
 ARCAM 141 077
 ATLANTIC TECHNOLOGY 342
 AUDIO FILE 071
 B AND K 096 097
 BOSE 070 170
 BOSTON ACOUSTICS 447
 CAMBRIDGE AUDIO 684
 CARVER 006 028 061 071 201 214 226 185 013 077 284
 CARY AUDIO DESIGN 378
 CITATION 148
 CLARION 026
 DENON 109 215 230 234 330 340 679 569
 DIGITAL PROJECTION 660
 DVICO 570
 ELAN 057 290
 ENLIGHTENED AUDIO 099 098
 ESCIENT 451
 FISHER 214 182